

Reversible vibratory plates **FB255** Spare Parts List



TABLE OF CONTENT

1. Decals 5

2. Electric system 6

 2.1. Electric components, panel 7

 2.2. Battery, parts 8

 2.3. Buzzer 9

 2.4. Electric components, handle 10

3. Engine cpl. 11

 3.1. Mounting parts 12

 3.2. Hand start parts 13

 3.2. Hand start cpl. 14

 3.3. Mounting parts 15

 3.4. Mounting parts 16

 3.5. Mounting parts 17

 3.6. Oil drain hose, parts 18

 3.7. Mounting parts 19

 3.8. Mounting parts 20

 3.10. Mounting parts 21

 3.11. Centrifugal clutch, parts 22

 3.11. Centrifugal clutch cpl. 23

 3.12. Engine, parts 24

 3.12. Engine cpl. Unto 2019 April 25

 3.12. Engine cpl. From 2019 May 26

 3.13. Nozzle, parts 27

4. Panel, parts 28

5. Hydraulic system 29

 5.1. Hydraulic mounting, parts 30

 5.2. Cylinder, parts 31

 5.3. Hydraulic pump, parts 32

 5.4. Hydraulic, hoses 33

 5.5. Hydraulic mounting, parts 34

 5.6. Hydraulic, handle 35

6. Hydraulic handle 36

7. Throttle, parts 37

8. Protective frame, parts 38

9. Protective frame 39

10. Handle 40

 10.1. Handle, parts 41

 10.2. Hook, parts 42

 10.3. Handle attachment, parts 43

11. Chassi 44

 11.1. Handle joints, parts 45

 11.2. Battery box, parts 46


 11.3. Belt tensioner 47

 11.3.1. Belt tensioner, cpl 48

 11.3.1. Belt tensioner, parts 49


11.4. Chassi, parts	50
12. Vibrations unit	52
12.1. Shaft with cog wheel, parts	53
12.2. Coupling shaft	55
12.3. V-belt	56
12.4. Housing, parts	57
13. Base plate cpl.	58
14. Vulkollan plate (Accessories)	59
14.1. Vulkollan plate, parts	60
14.1. Vulkollan plate, complete	61
15. Service kit	62

1. DECALS




Pos	Part.No	Label	No
1	207065	DECAL	1
2	307092	DECAL ENGINE SPEED CONTROL	1
3	304064	DECAL FB255	2
4	305032	DECAL	1
5	303122	DECAL	1

2. ELECTRIC SYSTEM




Pos	Label
1	Electric components, panel
2	Battery, parts
3	Buzzer
4	Electric components, handle

2.1. ELECTRIC COMPONENTS, PANEL




Pos	Part.No	Label	No
1	100911	CIRCUIT BREAKER VIBR. ON / OFF	1
2	100915	LED ELEMENT	2
3	100903	START SWITCH	1
4	303121	WIRING HARNESS	1
5	303127	CABLE	1

2.2. BATTERY, PARTS




Pos	Part.No	Label	No
1	303125	BATTERY CABLE +	1
2	303126	BATTERY CABLE -	1
3	100977	BATTERY	1

2.3. BUZZER




Pos	Part.No	Label	No
1	301255	BRACKET	1
2	100974	BUZZER CPL.	1

2.4. ELECTRIC COMPONENTS, HANDLE




Pos	Part.No	Label	No
1	100909	CIRCUIT BREAKER HANDLE HEATING	1
2	301170	HANDLE HEATER	1
3	303121	WIRING HARNESS	1

3. ENGINE CPL.



Pos	Label
1	Mounting parts
2	Hand start parts
2	Hand start cpl.
3	Mounting parts
4	Mounting parts
5	Mounting parts
6	Oil drain hose, parts
7	Mounting parts
8	Mounting parts
10	Mounting parts
11	Centrifugal clutch, parts
11	Centrifugal clutch cpl.
12	Engine, parts
12	Engine cpl. Unto 2019 April
12	Engine cpl. From 2019 May
13	Nozzle, parts

3.1. MOUNTING PARTS



Pos	Part.No	Label	No
1	101866	KEY	1
2	202231	DISTANCE SLEEVE	1
3	202020	WASHER	1
4	100106	BOLT / MF6S 8x20 8.8 fzb	1
5	100136	BOLT / M6S 10x40 8.8 fzb	4
6	100310	WASHER / HS12	4
7	100301	WASHER / BRB 8,4x16 HB200 fzb	4
8	100439	RUBBER-COVERED CLIP / 22 mm	1

3.2. HAND START PARTS




Pos	Part.No	Label	No
1	101950	START HANDLE	1
2	101951	ROPE, RECOIL STARTER	1

3.2. HAND START CPL.




Pos	Part.No	Label	No
1	101267	HAND START	1

3.3. MOUNTING PARTS




Pos	Part.No	Label	No
1	101866	KEY	1
2	202231	DISTANCE SLEEVE	1
3	202020	WASHER	1
4	100106	BOLT / MF6S 8x20 8.8 fzb	1
5	100136	BOLT / M6S 10x40 8.8 fzb	4
6	100310	WASHER / HS12	4
7	100301	WASHER / BRB 8,4x16 HB200 fzb	4
8	100439	RUBBER-COVERED CLIP / 22 mm	1

3.4. MOUNTING PARTS




Pos	Part.No	Label	No
1	101866	KEY	1
2	202231	DISTANCE SLEEVE	1
3	202020	WASHER	1
4	100106	BOLT / MF6S 8x20 8.8 fzb	1
5	100136	BOLT / M6S 10x40 8.8 fzb	4
6	100310	WASHER / HS12	4
7	100301	WASHER / BRB 8,4x16 HB200 fzb	4
8	100439	RUBBER-COVERED CLIP / 22 mm	1

3.5. MOUNTING PARTS




Pos	Part.No	Label	No
1	101866	KEY	1
2	202231	DISTANCE SLEEVE	1
3	202020	WASHER	1
4	100106	BOLT / MF6S 8x20 8.8 fzb	1
5	100136	BOLT / M6S 10x40 8.8 fzb	4
6	100310	WASHER / HS12	4
7	100301	WASHER / BRB 8,4x16 HB200 fzb	4
8	100439	RUBBER-COVERED CLIP / 22 mm	1

3.6. OIL DRAIN HOSE, PARTS




Pos	Part.No	Label	No
1	202066	PLUG	1
2	100609	O-RING / 6,3x2,4 NBR 70	1
3	101310	BLEEDER PIPE	1
4	101010	RUBBER/STEEL WASHER R3/8	1
5	101026	COUPLING / R3/8UF-M16x1,5UF	1
6	101030	PIPE CONNECTOR / R3/890T-3/8	1
7	100414	HOSE CLIP	1

3.7. MOUNTING PARTS




Pos	Part.No	Label	No
1	101866	KEY	1
2	202231	DISTANCE SLEEVE	1
3	202020	WASHER	1
4	100106	BOLT / MF6S 8x20 8.8 fzb	1
5	100136	BOLT / M6S 10x40 8.8 fzb	4
6	100310	WASHER / HS12	4
7	100301	WASHER / BRB 8,4x16 HB200 fzb	4
8	100439	RUBBER-COVERED CLIP / 22 mm	1

3.8. MOUNTING PARTS




Pos	Part.No	Label	No
1	101866	KEY	1
2	202231	DISTANCE SLEEVE	1
3	202020	WASHER	1
4	100106	BOLT / MF6S 8x20 8.8 fzb	1
5	100136	BOLT / M6S 10x40 8.8 fzb	4
6	100310	WASHER / HS12	4
7	100301	WASHER / BRB 8,4x16 HB200 fzb	4
8	100439	RUBBER-COVERED CLIP / 22 mm	1

3.10. MOUNTING PARTS




Pos	Part.No	Label	No
1	101866	KEY	1
2	202231	DISTANCE SLEEVE	1
3	202020	WASHER	1
4	100106	BOLT / MF6S 8x20 8.8 fzb	1
5	100136	BOLT / M6S 10x40 8.8 fzb	4
6	100310	WASHER / HS12	4
7	100301	WASHER / BRB 8,4x16 HB200 fzb	4
8	100439	RUBBER-COVERED CLIP / 22 mm	1

3.11. CENTRIFUGAL CLUTCH, PARTS




Pos	Part.No	Label	No
1	100820	BALL BEARING 6008.2Z	1
2	100836	SPRING	4
3	100120	BOLT / MF6S 4x12 10.9	2
4	100817	END CAP	1
5	100811	CLUTCH LINING	2
6	100824	HUB	1

3.11. CENTRIFUGAL CLUTCH CPL.




Pos	Part.No	Label	No
1	100844	CLUTCH	1

3.12. ENGINE, PARTS




Pos	Part.No	Label	No
1	101936	MUFFLER	1
2	101926	REGULATOR	1
3	101252	DIP STICK / YANMAR	1
4	101711	OIL PRESSURE CONTACT	1
5	101937	RADIAL SEALING, CRANKSHAFT	1
6	101938	SEAL, CRANKCASE	1
7	101939	PIPE, FUEL OIL	1
8	101265	FUEL COCK	1
9	101212	FUEL FILTER	1
10	101940	TANK-FUEL	1
11	101228	TANK COVER	1
12	101941	FUEL PUMP ASSY	1
13	101860	AIR FILTER	1
14	101942	AIR FILTER LOCK	1
15	101943	NUT	1
16	101944	BONNET ASSY, HEAD	1
17	101945	VALVE HOUSING SEAL	1
18	101840	STARTER	1
19	101226	SOLENOID	1
20	101946	GASKET, MUFFLER	1

3.12. ENGINE CPL. UNTO 2019 APRIL




Pos	Part.No	Label	No
1	101859	DIESELEngine / YANMAR L70N	1

3.12. ENGINE CPL. FROM 2019 MAY




Pos	Part.No	Label	No
1	1018105	DIESEL ENGINE / YANMAR L70V	1

3.13. NOZZLE, PARTS




Pos	Part.No	Label	No
1	101947	FUEL INJECTOR	1
2	101948	NOZZLE	1
3	101949	SEAL	1

4. PANEL, PARTS




Pos	Part.No	Label	No
1	100413	RUBBER-COVERED CLIP / 10 mm	2
2	303110	PANEL	1
3	1001142	BOLT / M6SF 5x12 FZB	2
4	100462	RUBBER-COVERED CLIP 19 mm-M8	1
5	303146	DECAL	1
6	1001125	BOLT / M6SF 8x16 8.8 FZB	3
7	303109	BRACKET	1

5. HYDRAULIC SYSTEM




Pos	Label
1	Hydraulic mounting, parts
2	Cylinder, parts
3	Hydraulic pump, parts
4	Hydraulic, hoses
5	Hydraulic mounting, parts
6	Hydraulic, handle

5.1. HYDRAULIC MOUNTING, PARTS




Pos	Part.No	Label	No
1	1001444	BREATHER CAP	1
2	303025	HYDRAULIC OIL TANK	1
3	303267	PLATE	1
4	1010042	ADAPTER	1
5	1010040	DOUBLE CLAMP	1
6	1001129	BOLT / M6SZ 8x25 FZB	1
7	303052	BEARING CAP	1
8	1010040	DOUBLE CLAMP	1
9	1001129	BOLT / M6SZ 8x25 FZB	1
10	101007	COUPLING / R1/4UF-R1/4UF	2
11	1010042	ADAPTER	2
12	101003	COUPLING R1/4"UF-R1/4"UF	3

5.2. CYLINDER, PARTS




Pos	Part.No	Label	No
1	100114	BOLT / MC6S 8x20 8.8 fzb	1
2	303060	CYLINDER	1
3	101007	COUPLING / R1/4UF-R1/4UF	1
4	101009	RUBBER/STEEL WASHER R1/4	1
5	100114	BOLT / MC6S 8x20 8.8 fzb	2
6	100301	WASHER / BRB 8,4x16 HB200 fzb	2

5.3. HYDRAULIC PUMP, PARTS




Pos	Part.No	Label	No
1	100149	BOLT / MC6S 6x20 8.8 fzb	2
2	100325	WASHER / HS 6	2
3	100300	WASHER / BRB 6,4x12 HB200 fzb	2
4	101037	HYDRAULIC PUMP	1
5	100117	BOLT / MC6S 8x25 8.8 fzb	3
6	100611	O-RING / 22,22x2,62 NBR 70	1
7	303053	PUMP FLANGE	1
8	100600	O-RING / 89,5x3 NBR 70	1
9	201516	CLAW COUPLING	1
10	100808	GEAR RIM	1
11	100146	BOLT / MS6SS 4x6 SS	1
12	100301	WASHER / BRB 8,4x16 HB200 fzb	3
13	101092	RUBBER/STEEL WASHER M14	2
14	101091	COUPLING / R1/4 UF- M14x1,5UF	2

5.4. HYDRAULIC, HOSES




Pos	Part.No	Label	No
1	303102	HYDRAULIC HOSE	1
2	304502	HYDRAULIC HOSE	1
3	304503	HYDRAULIC HOSE	1
4	304501	HYDRAULIC HOSE	1
5	303099	HYDRAULIC HOSE	1
6	303262	HYDRAULIC HOSE	2

5.5. HYDRAULIC MOUNTING, PARTS




Pos	Part.No	Label	No
1	1001444	BREATHER CAP	1
2	303025	HYDRAULIC OIL TANK	1
3	303267	PLATE	1
4	1010042	ADAPTER	1
5	1010040	DOUBLE CLAMP	1
6	1001129	BOLT / M6SZ 8x25 FZB	1
7	303052	BEARING CAP	1
8	1010040	DOUBLE CLAMP	1
9	1001129	BOLT / M6SZ 8x25 FZB	1
10	101007	COUPLING / R1/4UF-R1/4UF	2
11	1010042	ADAPTER	2
12	101003	COUPLING R1/4"UF-R1/4"UF	3

5.6. HYDRAULIC, HANDLE




Pos	Part.No	Label	No
1	1010006	VALVE	1
2	1010026	A ACTUATOR HOUSING, TYPE ATLANTIC FLUID	1
3	101009	RUBBER/STEEL WASHER R1/4	8
4	101067	COUPLING	3
5	303262	HYDRAULIC HOSE	2
6	303102	HYDRAULIC HOSE	1

6. HYDRAULIC HANDLE




Pos	Part.No	Label	No
1	101099	B VALVE, TYPE CBF BM024004	1
1	1010005	A VALVE, TYPE ATLANTIC FLUID Type Atlantic fluid EXPIRED	1
2	1010001	B ACTUATOR HOUSING, TYPE CBF	1
2	1010026	A ACTUATOR HOUSING, TYPE ATLANTIC FLUID	1
3	101009	RUBBER/STEEL WASHER R1/4	8
4	101067	COUPLING	3
5	303262	HYDRAULIC HOSE	2
6	303102	HYDRAULIC HOSE	1

7. THROTTLE, PARTS



Pos	Part.No	Label	No
1	101117	THROTTLE	1
2	100118	BOLT / MC6S 6x30 8.8 fzb	2
3	301249	THROTTLE CABLE	1
4	101121	ADJUSTING BOLT	1
5	100223	NUT / M6MF M6	2
6	101865	THROTTLE CABLE MOUNTING PARTS	1
7	100222	NUT / LOCKING M6MF M6	2
8	101118	NIPPLE	1

8. PROTECTIVE FRAME, PARTS




Pos	Part.No	Label	No
1	304039	COVER	1
2	304035	PROTECTIVE FRAME	1
3	100310	WASHER / HS12	2
4	100125	BOLT / M6S 12x20 8.8 fzb	2
5	100310	WASHER / HS12	1
6	100168	BOLT / M6S 12x30 8.8 fzb	2
7	100207	NUT / LOCKING6 BH8 låg fzb	4
8	304034	BRACKET	1

9. PROTECTIVE FRAME




Pos	Part.No	Label	No
1	304602	PROTECTIVE FRAME CPL.	1

10. HANDLE




Pos	Label
1	Handle, parts
2	Hook, parts
3	Handle attachment, parts

10.1. HANDLE, PARTS




Pos	Part.No	Label	No
1	1001136	BOLT / M6SF 6x10 fzb	2
2	308165	HANDLE	1
3	303012	HANDLE BRACKET	1
4	1001127	BOLT / M6SF 10x14 FZB	4
5	100746	VIBRATIONS ISOLATOR	4
6	1001127	BOLT / M6SF 10x14 FZB	4
7	100191	SCREW / K6S 6X12 4.2 fzb	2
8	1009020	CABLE BUSHING	1
9	1001126	BOLT / M6SZ 6x16 FZB	8
10	307681	COVER PLATE	1
11	100223	NUT / M6MF M6	4
12	306517	BRACKET	2
13	101123	SPACE RING	4
14	100987	COVER	2
15	101188	SCREW / MC6S 8X16 8.8 FZB	2
16	307813	HANDLE CPL	1

10.2. HOOK, PARTS



Pos	Part.No	Label	No
1	203162	HOOK	1
2	100309	WASHER / SRKB 9x28x2 HB200 fzb	1
3	1001124	SCREW / M6SF 8x12 8.8 FZB	1
4	303012	HANDLE BRACKET	1

10.3. HANDLE ATTACHMENT, PARTS




Pos	Part.No	Label	No
1	201547	CLEAT RIGHT	1
2	201548	CLEAT LEFT	1
3	100708	IMPACT DAMPER	2
4	100129	BOLT / MC6S 8x12 8.8 fzb	2
5	201550	STUD SCREW	1
6	201526	BUSHING	2
7	100221	NUT / LOCKING M6MF M8	2

11. CHASSI




Pos	Label
1	Handle joints, parts
2	Battery box, parts
3	Belt tensioner
4	Chassi, parts

11.1. HANDLE JOINTS, PARTS




Pos	Part.No	Label	No
1	100151	BOLT / M6S 10x25 8.8 fzb	4
2	100702	SUSPENSION UNIT	1
3	201640	MOUNTING CLAMP	1
4	100220	NUT / LOCKING M6MF M10	4

11.2. BATTERY BOX, PARTS




Pos	Part.No	Label	No
1	100223	NUT / M6MF M6	4
2	100725	VIBRATION ISOLATOR	4
3	1001115	BOLT / MELC6S M6x8 10.9 FZB	4
4	203194	STRAP	1
5	303067	BATTERY BOX	1

11.3. BELT TENSIONER




Pos	Label
1	Belt tensioner, cpl
1	Belt tensioner, parts

11.3.1. BELT TENSIONER, CPL




Pos	Part.No	Label	No
1	303104	BELT TENSIONER	1

11.3.1. BELT TENSIONER, PARTS



Pos	Part.No	Label	No
1	303097	SHAFT	1
2	100465	CIRCLIP / SGH 42	2
3	100530	BEARING / 6004 DDU C3 ENSS6	1
4	303096	BELT WHEEL	1
5	100466	CIRCLIP / SGA 20	1


11.4. CHASSI, PARTS



Pos	Part.No	Label	No
1	1001139	BOLT / M6SZ 10x20	2
2	100745	IMPACT DAMPER	1
3	1001144	BOLT / M6SF 6x16 FZB	1
4	303118	BUFFER BRACKET	2
5	100222	NUT / LOCKING M6MF M6	15
6	304017	CHASSI	1
7	301128	BRACKET	1
8	303030	BUFFER	1
9	100107	BOLT / M6S 12x16 8.8 fzb	4
10	303123	INNER BELT COVER	1
11	303104	BELT TENSIONER	1
12	100310	WASHER / HS12	4
13	100154	BOLT / MC6S 12x20 8.8 fzb	4
14	100314	WASHER 13x30x4 HB305 VFZB	1
15	100310	WASHER / HS12	1
16	1001145	BOLT / M6S 12x25 8.8 FZB	1
17	1001127	BOLT / M6SF 10x14 FZB	4
18	303190	BELT GUARD	1
19	304064	DECAL FB255	1
20	1001103	SCREW / MELC6S 8x12 10.9	4
21	301172	BRACKET	2


22	303191	BATTERY COVER	1
23	1001111	BOLT / M6SF 6x12 8.8 fzb	2

12. VIBRATIONS UNIT



Pos	Label
1	Shaft with cog wheel, parts
2	Coupling shaft
3	V-belt
4	Housing, parts


12.1. SHAFT WITH COG WHEEL, PARTS



Pos	Part.No	Label	No
1	100463	CIRCLIP / SGH 26	1
2	100368	SPRING	1
3	100100	BOLT / M6S 8x20 8.8 fzb	1
4	100306	WASHER / SRKB 9x35x3 HB200 fzb	1
5	1001181	SCREW / MS6SS 8x12	1
6	303304	CONTROL ROD	1
7	100434	CIRCLIP / SGA 60	1
8	303183	COG WHEEL	1
9	304043	COG WHEEL	1
10	100543	BALL BEARING / 61808	2
11	304019	SLEEVE	1
12	100446	FLAT KEY / RK 6x6x10 H9	1
13	100443	CIRCLIP / SGH 22	1
14	303298	SPACER	1
15	100526	BALL BEARING / 61900	2
16	100445	CIRCLIP / SGA 10	1
17	301204	PISTON	1
18	100627	O-RING / 24,2x3 VITON	2
19	304041	SHAFT COMPLETE	1
20	100505	ROLLER BEARING / NJ 308E-C3	2
21	303098	WEIGHT	2

22	100301	WASHER / BRB 8,4x16 HB200 fzb	4
23	100313	WASHER / HS10	4
24	100104	BOLT / MC6S 10x45 12,9	4
25	303181	SHAFT	1
26	303185	CYLINDRIC PIN, HARDENED	1
27	100506	SLIDE BEARING	2
28	100431	CIRCLIP / A40x1,75K	2
29	100431	CIRCLIP / A40x1,75K	2

12.2. COUPLING SHAFT




Pos	Part.No	Label	No
1	303098	WEIGHT	2
2	100301	WASHER / BRB 8,4x16 HB200 fzb	4
3	100104	BOLT / MC6S 10x45 12,9	4
4	100313	WASHER / HS10	4
5	203029	COG WHEEL	1
6	100604	RADIAL SEALING / 25x35x6 CCP VITON	1
7	100400	FLAT KEY / RK 6x6x30 H9	1
8	207008	V-BELT PULLEY	1
9	100306	WASHER / SRKB 9x35x3 HB200 fzb	1
10	100100	BOLT / M6S 8x20 8.8 fzb	1
11	100502	INNER RING / LRT 20x25x20,5	1
12	303065	MOUNTED SHAFT	1
13	100410	FLAT KEY / RK 10x8x36	1
14	100411	CIRCLIP / SGA 45	1
15	100431	CIRCLIP / A40x1,75K	1
16	100505	ROLLER BEARING / NJ 308E-C3	2

12.3. V-BELT




Pos	Part.No	Label	No
1	100890	V-BELT XPA 1000	1

12.4. HOUSING, PARTS




Pos	Part.No	Label	No
1	100111	BOLT / MC6S 12x160 12.9	4
2	100303	WASHER / BRB 13,0x24 HB200 fzb	4
3	304034	BRACKET	2
4	100207	NUT / LOCKING6 BH8 låg fzb	8
5	304072	COVER	1
6	304079	BELT GUARD	1
7	1001126	BOLT / M6SZ 6x16 FZB	4
8	303135	COVER	1
9	100100	BOLT / M6S 8x20 8.8 fzb	1
10	100306	WASHER / SRKB 9x35x3 HB200 fzb	1
11	207008	V-BELT PULLEY	1
12	100400	FLAT KEY / RK 6x6x30 H9	1
13	1001107	BOLT / M6SF 8x20 8.8 FZB	6
14	100604	RADIAL SEALING / 25x35x6 CCP VITON	1
15	100600	O-RING / 89,5x3 NBR 70	2
16	303062	HOUSING	1
17	203133	SEAL	1
18	100100	BOLT / M6S 8x20 8.8 fzb	18
19	100326	WASHER / HS 8	18
20	203031	LOCK	1

13. BASE PLATE CPL.




Pos	Part.No	Label	No
1	100125	BOLT / M6S 12x20 8.8 fzb	4
2	100303	WASHER / BRB 13,0x24 HB200 fzb	4
3	100732	VIBRATIONS ISOLATOR	4
4	303027	BASE PLATE	1

14. VULKOLLAN PLATE (ACCESSORIES)




Pos	Label
1	Vulkollan plate, parts
1	Vulkollan plate, complete

14.1. VULKOLLAN PLATE, PARTS



Pos	Part.No	Label	No
1	201045	BRACKET	2
2	100318	WASHER / SRKB 11x35x3 HB200 fzb	4
3	100220	NUT / LOCKING M6MF M10	4

14.1. VULKOLLAN PLATE, COMPLETE



Pos	Part.No	Label	No
1	303139	VULKOLLAN PLATE, COMPLETE	1

15. SERVICE KIT

Pos	Part.No	Label	No
1	102122	SERVICEKIT FB255	1
	-	Including parts:	
0	101860	AIR FILTER	1
0	101212	FUEL FILTER	1
0	100890	V-BELT XPA 1000	1
	-		

